




Rama TA-2

Zakres dostawy




2x		2x		1x		2x			
8x	8x	4x	4x	4x	4x				
M6x10 (H4)	M6x12 (H5)	M6x20 (H5)	Ø6.4/Ø11x1.6	M10 (Hex 17)	-				
8x	8x	2x	3x	1x	1x	4x	10x	10x	
6x25 (T30)	Ø6.4/Ø16x1.6	5x20 (T25)	6x50 (T30)	6x80 (T30)	-	3.5x20 (T15)	27x27	3.5x200	















Rama TA-4

Zakres dostawy


4x		2x		1x				
16x	4x	4x	4x	4x	16x	16x		
M6x12 (H5)	M6x25 (H5)	M10 (Hex 17)		-	M6x25 (H4)	M8x12 (H6)		
16x	16x	2x	3x	1x	1x	4x	10x	10x
6x30 (T30)	Ø6.4/Ø16x1.6	5x20 (T25)	6x50 (T30)	6x80 (T30)	-	3.5x20 (T15)	27x27	3.5x200




Podłączenie węża do pompy

 	1 Zmierz długość węża od elementu podnoszącego do pompy.	 $R \geq 25 \text{ mm}$     40°C max.  0°C min.
2 	 	
3 	 	
4 	 PA  PF  PB   OK	

Montaż pompy PA/PF/PB z korbą ręczną pod blatem



Montaż pompy PA/PF/PB z napędem silnikowym pod blatem



Ergoswiss AG
Nöllenstrasse 15a
CH-9443 Widnau
Tel.: +41 (0) 71 727 06 70
Fax: +41 (0) 71 727 06 79

info@ergoswiss.com
www.ergoswiss.com